




Montážny návod - Provensal

2 / 7




A	B	C (mm)		D
1	S330-002	475,5	186	1/1
2	S330-003	475,5	186	1/1
3	S330-004	648	476	1/1
4	S330-005	648	476	1/1
5	S330-101	846	342	1/1
6	S330-102	846	342	1/1
7	S330-103	185	326	1/1
8	S330-201	960	380	1/1
9	S330-202	960	363	1/1
10	S330-301	928	320	1/1
11	S330-305	929	325	1/1
12	S330-902	856	938	1/1
13	S330-903	430	305	1/1
14	ZS3-5647	408	140	1/1
15	ZS4-543	300	140	1/1
16	ZS4-544	300	140	1/1




4x a44	4x b19	4x c193 160 mm	8x d1 n 5x17 mm	9x e3 Ø6x13 mm	8x e19 Ø5x9 mm	16x f1 Ø8x30 mm	4x f9 Ø6x30 mm	8x f25 Ø6,5x40 mm	5x k43	10x l1	10x l2	1x n14 81x21x15/1,5
2x o21 silikon	8x p9 Ø4x30 mm	8x p38 Ø3,5x16 mm	8x p51 Ø3,5x15 mm	3x p54 Ø3x12 mm	16x r1 Ø15x12 mm #16	8x r15 Ø12x10,5 mm #12	24x r42 20/11	7x s2 Ø16	2x w37\CL 300 mm	2x w37\CR 300 mm	2x w37\DL 300 mm	2x w37\DR 300 mm

1 

3 / 7








2 









4

5








5 / 7



6



6 / 7



7

